

NeuraLaserColor 2: Shortening the paper “tail”

Because the NeuraLaserColor 2 prints at high speeds, it takes time to slow the printer at the end of a print, leading to additional blank pages (paper tail) on the end of the print. To shorten the tail use **Cut Adjust Left**, found on the Printer Web Server. **Cut Adjust Left** controls when job starts to slow down at the end of a print in order to stop sooner and shorten the tail. Make sure this value is set to **12.9**. If you wish to further shorten the tail, Default speed (rather than High speed) can be used and Cut Adjust Left can be set to a value of **20**. This allows the printer to slow sooner and will result in a shorter paper tail. It is possible to increase **Cut Adjust Left** value further using High Speed, however this might result in a defect in the last inch of the well log print. If this becomes a problem, this value should be lowered back to 12.9. **This feature requires Firmware Engine Version E239 released on 5/27/2014 (or later).**

To change **Cut Adjust Left** and shorten the print tail:

- Bring up a web browser window, such as Internet Explorer or Chrome.
- Type in the printer’s assigned IP address in the browser address bar.
- If your printer is turned ON and the network connection set up properly, you will see your printer’s interface web page.
- Select **Settings** from the Left Menu and then **Continuous Print**.
- Set Cut Adjustment Left to **12.9** to shorten the print tail.
- If you wish to change Maximum Print Speed to Default (from High), a value of **20** will further shorten the tail.

Device Status		Settings	
Copy Printer Settings		Default Settings	
Settings		General Settings	
		Bookmark Setup	
		Other Settings	
		Network/Ports Update Firmware Security E-mail Alert Setup Intervention Management Import/Export Device Solutions Continuous Print	
Image Stitch	<input checked="" type="checkbox"/>		
Cut between copies	<input checked="" type="checkbox"/>		
Cut between jobs	<input checked="" type="checkbox"/>		
Image Gap (no marks)	<input type="text" value="0.000"/>	inches (0=use default)	
Leading Blank Space	<input type="text" value="0.500"/>		
Trailing Blank Space	<input type="text" value="0.000"/>		
Leading Blank Speed	<input type="text" value="Use Current Print Speed"/>		
Initial Page Top Margin Adjustment	<input type="text" value="0.000"/>	inches (0=disabled)	
Top Margin Adjustment	<input type="text" value="0.125"/>	inches (0=disabled)	
Mark Adjustment	<input type="text" value="2.000"/>		
Image Size Adjustment	<input type="text" value="0"/>		
Cut Adjustment Left	<input type="text" value="0.000"/>	<div style="border: 1px solid red; padding: 2px; display: inline-block;"> 12.9 HIGH SPEED 20 DEFAULT SPEED </div>	
Cut Adjustment Right	<input type="text" value="0.000"/>		
Use Mark	<input checked="" type="checkbox"/>		
Auto Calibrate Marks	<input type="text" value="0"/>		
Form Size	<input type="text" value="0.000"/>	inches (0=disabled)	
Maximum Print Speed	<input type="text" value="High"/>		
Fuser Temp Offset	<input type="text" value="0"/>	deg C (0=normal)	
Second Transfer Voltage Offset	<input type="text" value="0"/>	volts (0=disabled)	